



## **INSTALLATION SPECIFICATION PENNCOAT™ 101 MEMBRANE**

### **1. SCOPE**

- 1.1 *This specification governs the installation of Penncoat 101 hot melt multi-layer asphalt membrane lining system. It consists of a cut back asphalt primer (Pennprime™ 101), a hot melt applied asphalt membrane layer (Penncoat 101) and a mat reinforcing player (Pennply™ 101).*

### **2. APPLICATION**

- 2.1 *Concrete shall be poured to proper grade and wood floated. It shall be free of high and low spots, and from pits, cavities or honeycombing. To insure good drainage slope should be 1/4" to the foot (20 mm to the meter).*
- 2.2 *Allow concrete to dry to touch. Apply a single coat of Pennprime 101 asphalt primer with a stiff brush scrubbing thoroughly into the concrete until all floor areas show black color. Allow primer to dry until it is dry (not tacky) to touch.*
- 2.3 *Penncoat 101 Membrane is a solid asphalt product. It must be heated to be applied. For best results, Penncoat 101 should be heated to and applied between 325°F-400°F (163°C-204°C). Lower temperatures will result in difficulty in applying. Higher temperatures can result in loss of properties.*
- 2.4 *Care should be used in the initial heating of a kettle containing cold solid asphalt. Apply heat slowly until the area around the heating tubes is liquid, then increase the heating rate as additional quantities of solid asphalt are added. Excessive temperatures can cause coke to form around heating tubes. This coke should be removed as soon as possible as it will serve as an insulator resulting in poor heat transfer and premature tube failure.*
- 2.5 *Melt PENNCOAT 101 hot membrane and apply by squeegee to a minimum thickness of 1/8" (3 mm). Do not use mops or brushes to apply the membrane as wicking from loose random strands may cause pinholes in the membrane.*
- 2.6 *Roll a single ply of Pennply 101 glass reinforcing cloth into the top surface. Overlap all edges 2" (50 mm) and smooth out any wrinkles or bulges with a squeegee while Penncoat 101 is still soft.*
- 2.7 *Apply a second 1/8" (3 mm) coat of Penncoat 101 Membrane as in Paragraph 2.5, to provide a minimum over-all thickness of 1/4" (6.4 mm).*
- 2.8 *If so specified, a second layer of cloth and a third 1/8" (3.2 mm.) layer of asphalt may be applied, for a minimum total membrane thickness of 3/8" (9.5 mm). This is often recommended in trenches, pits,*

*and sumps.*

- 2.9 *Powdered silica flour (325 mesh size) may be very lightly dusted over membrane surface to prevent sticking of workmen's shoes as they walk across freshly applied first layer of the Penncoat 101.*

**3. CLEANUP**

- 3.1 *Use mineral spirits for cleaning Pennprime and Penncoat residue.*

**4. SAFETY PRECAUTIONS DISCLAIMER CONTACT INFORMATION**

- 4.1 Consult current Safety Data Sheets (SDS's) before commencement of work.

- 4.2 While statements, technical information and recommendations contained herein are based on information our company believes to be reliable, nothing contained herein shall constitute any warranty, express or implied, with respect to the products and/or services described herein, and any such warranties are expressly disclaimed. We recommend that the prospective purchaser or user independently determine the suitability of our product(s) for their intended use. No statement, information, or recommendation with respect to our products, whether contained herein or otherwise communicated, shall be legally binding upon us unless expressly set forth in a written agreement between us and the purchaser/user. For all Terms and Conditions of Sale see <https://www.ergonarmor.com/about-ergon-inc/terms-and-conditions>.

- 6.3 Please contact ErgonArmor for further information at +1-601-933-3595 or [ErgonArmorCustServ@ergon.com](mailto:ErgonArmorCustServ@ergon.com).

***ergonarmor.com***